

STEALTH 340 APPLICATIONS

Acura

Integra 1994-2001	#11542
NSX 1991-2000	#11541
RSX 2002-current	#11542

Chrysler/Dodge/Plymouth

FWD 1984-1990 340	#11540
Stealth T/T 1991-1997	#11541
Eagle Talon 1995-1998 Turbo	#11542
Eagle Talon 1990-1994 AWD	#11541
Eagle Talon 1990-1994 FWD	#11542
Laser 95-98 Turbo AWD&FWD	#11542
Laser 1990-1994 AWD Turbo	#11541
Laser 1990-1994 FWD Turbo	#11542

Ford Truck

Lightning 99-00	#11542 (x2)
F150 1997-1998	#11542
F150 1999-2004	#11542

Ford

Mustang 1985-1997 (except Cobra)	#11540
Mustang Cobra 1996-1997	#11542
Probe GT 1988-1992	#11541
Probe GT 1993-1997	#11542
Crown Vic/Marauder 03-04	#11542

General Motors

Grand National / Regal 1982-1987	#11569
Camaro 5.0L & 5.7L 1985-1992	#11569
Corvette 5.0L & 5.7L 1985-1992	#11569
GM Cars & Trucks 1985-1992	#11569
305 (5.0L) & 350 (5.7L) 87-97	#11569
S10, S15, Sonoma, Blazer, Envoy 82-95	#11569
Firebird 5.0L & 5.7L 1985-1992	#11569
Fiero 2.8L 1985-1986	#11569
Cyclone 1991-1992	#11569
Typhoon 1992-1993	#11569
Saturn SC,SL,SW 1997-2002	#11542

Honda

Accord 1990-1993	#11541
Accord 1994-1997	#11542
Accord 1998-2002	#11542
Civic 1988-1991	
Civic 1992-2000	#11142
CRX 1989-1991	#11541
Prelude 1985-1987	
Prelude 1992-1996	#11541
Prelude 1997-2001	#11542

Hyundai

Tiburon 97-01	#11542
---------------	--------

Mazda

Miata 1994-1997	#11542
Miata 1999-2005	#11542
MX6 1988-1992	#11541
MX6 1993-1997	#11542
Protégé 90-91	#11541
Protégé 95-98	#11542
RX7 1986-1988	#11541
RX7 1989-1992	#11541
RX7 1993-1995	#11541
323 1986-1991	#11541

Mitsubishi

3000GT TT 91-97	#11541
Eclipse 95-98 Turbo	#11542
Eclipse 90-94 AWD	#11541
Eclipse 90-94 FWD	#11542
Galant 1985-1990	#11542
*EVO 8&9 2003-2007	#11542

- Factory basket assembly MUST be replaced before converting to a 340 Stealth Pump.
- Note: If converting to E85, factory basket assembly MUST be eliminated or modified

Jeep

Wrangler 91-97	#11542
Wrangler 97-04	#11542
Cherokee 97-01	#11542
Grand Cherokee 97-98	#11542

Lexus

GS300 1993-2000	#11542
GS400 1992-2000	#11542
SC300 1992-2000	#11542
SC400 1992-2000	#11542

Nissan

D21 Pick Up 86-95	#11542
200SX 1995-1998	#11542
200SX SE-R 95-98	#11542
240SX 1989-1994	#11541
240SX 1995-1998	#11541
300ZX 1990-1996	#11542
NX1600 91-94	#11541
NX2000 91-94	#11541
Sentra 1991-1994	#11541
Sentra 1998-1999	#11542
Sentra SE 98-99	#11542
Sentra SE-R 91-94	#11541
Maxima 84-94	#11541
Maxima 1998	#11541
Altima 1993-1995	#11541
Altima 1996-2001	#11542

Subaru

Impreza WRX 98-99	#11541
Impreza 2002-2006	#11542
Impreza WRX/STi 04-07	#11542

Toyota

MR2 1991-1996	#11541
Supra 1984-1992	#11541
Supra 1994-1998	#11542
Supra Turbo 84-92	#11541
Supra Turbo 94-98	#11541
T100 1993-1998	#11542
Tacoma 1995-2001	#11542
Celica 1985-1989	#11541
Celica 90-93 Turbo AWD	#11541
Celica 90-93 ST & GT	#11541
Corolla 1985-1992	#11541



#11542
Inlet In-Line
from Outlet



#11541
Inlet Offset
from Outlet



#11540
Center Inlet



#11569
Center offset
(GM app)

STEALTH 325 APPLICATIONS



Acura RSX 2002-2006 #11165

Ford

F150/F250 1997-2004	#11165
F150 Harley-Davidson 02-03	#11165
Focus RS I5 Turbo 09-10	#11165
Mustang 1999-2004	#11165
Mustang (exc. GT500) 05-10	#11165

Holden Commodore 07-13 #11165

Honda Civic 2006-2013 #11165

Honda Civic 2001-2005 #11165

Lotus Elise 2004+ #11165

Lotus Exige 2004+ #11165

Mazda

MazdaSpeed3 2007-2012 #11165

MazdaSpeed6 2006-2007 #11165

MX5 2006-2013 #11165

Mitsubishi EVO X 08-14 #11165

Nissan R35 GTR 08-14 #11165 (x2)

Pontiac GTO 2004-2006 #11165

Scion FR-S 2013+ #11165

Subaru

Legacy GT 2005-2009 #11165

WRX/STI 2008-2012 #11165

BRZ 2013+ #11165

Toyota

Celica 2000-2005 #11165

MR2 Spyder 2000-2005 #11165

Corolla 2003-2004 #11165

Matrix 2003-2004 #11165

